


•

Disassemble and remove the following items from the motor plate assembly. Keep the remaining items for the new assembly.

ITEM NO.	DESCRIPTION	QTY.
3	Left Motor Plate with Inserts	1
14	M3 Buttonhead Screw, 12mm long	4




В

	Left Assembly Part Harvesting			
(cc) (1)			last edited: 1/22/2020	
		SCALE: 1:1	SHEET 3 OF 12	

В

Disassemble and remove the following items from the motor plate assembly. Keep the remaining items for the new assembly.

ITEM NO.	DESCRIPTION	QTY.
5	M4 shoulder screw, 12mm-l, 5mm-d	2
6	M3 Buttonhead Screw, 12mm long	4
11	Right Motor Plate with Inserts	1





A

В

Right Assembly Part Harvesting			
Created by: Joshua Vasquez 1/22/2020			
		SCALE: 1:1	SHEET 4 OF 12

В






Α


ITEM NO.	DESCRIPTION	
1	M3 Standoff, 13mm long, 6mm wide	2
2	M3 Buttonhead Screw, 10mm long	2
3	Right Corner Motor Plate	1

Left Motor Plate Assembly 1/4			
CC	BY	Created by: Joshua Vasquez	last edited: 1/22/2020
		SCALE: 1:1	SHEET 5 OF 12

В




2




Α

ITEM NO.	DESCRIPTION	
4	M5 Buttonhead Screw, 20mm long	4
5	M5 Drop-In T-Nut for 20x20 Extrusion	4
6	Short Motor Corner Plate Spacer with Inserts	1

	Left Motor Plate Assembly 2/4			
<u>@</u>	(i) BY	Created by: Joshua Vasquez	last edited: 1/22/2020	
		SCALE: 1:1	SHEET 6 OF 12	





	Left Mo	otor Plate Asser	mbly 3/4
CC	BY	Created by: Joshua Vasquez	last edited: 1/22/2020
		SCALE: 1:1	SHEET 7 OF 12


В

A

В

2

•




Α


В

ITEM NO.	DESCRIPTION	QTY.
2	M3 Buttonhead Screw, 10mm long	6
14	M3 Washer	4
15	XY Drive Stepper with Pulley	1

	Left Motor Plate Assembly 4/4			
CC BY		Created by: Joshua Vasquez	last edited: 1/22/2020	
		SCALE: 1:1	SHEET 8 OF 12	

В





В

Α


ITEM NO.	DESCRIPTION	
1	Left Corner Motor Plate	1
2	M3 Standoff, 13mm long, 6mm wide	2
3	M3 Buttonhead Screw, 10mm long	2


Right Motor Plate Assembly 1/4			
<u></u>	BY	Created by: Joshua Vasquez	last edited: 1/22/2020
		SCALE: 1:1	SHEET 9 OF 12

ITEM NO.	DESCRIPTION	
3	Tall Motor Corner Plate Spacer Assembly	1
4	M5 Washer	4
5	M5 Buttonhead Screw, 30mm long	4
6	M5 Drop-In T-Nut for 20x20 Extrusion	4

В

Α







Right Motor Plate Assembly 2/4			
CC	BY	Created by: Joshua Vasquez	last edited: 1/22/2020
		SCALE: 1:1	SHEET 10 OF 12

2

•



ITEM NO.	TEM NO. DESCRIPTION	
3	20T Idler pulley, 2GT, 5mm bore	1
4	20T toothless idler, 5mm bore	1
5	pulley reinforcement plate for motor	1
6	M3 Buttonhead Screw, 6mm long	2
7	M4 Shoulder Screw, 16mm-I, 5mm-d	2
8	M5 Shim, 0.2mm thick	2
9	OpenBuilds M5 3mm Spacer	2




Right Motor Plate Assembly 3/4			
CC	(i)	Created by: Joshua Vasquez	last edited: 1/22/2020
-		SCALE: 1:1	SHEET 11 OF 12


2

•

Α

В





Α

В

ITEM NO.	DESCRIPTION	QTY.
14	M3 Buttonhead Screw, 10mm long	6
15	XY Drive Stepper with Pulley	1
16	M3 Washer	4

Right Motor Plate Assembly 4/4			
(0)	•	Created by: Joshua Vasquez	last edited: 1/22/2020
	ВҮ	SCALE: 1:1	SHEET 12 OF 12

В

Α