



Install the following inserts from the directions shown using the *plate press technique*.






Α

В


ITEM NO.	DESCRIPTION	QTY.
2	M3 Tapered Heat Set Insert	9

Heat Set Insert Installation			
		Created by:	last edited:
CC	BY	Joshua Vasquez	3/3/2020
		SCALE: 1:1	SHEET 2 OF 14



II LIVI INO.	DESCINII HON	QII.
1	Wedge Plate	1
2	Base Tool Plate with Inserts	1
3	M3 Flathead Screw, 8mm long	3


Wedge Plate Installation			
		Created by:	last edited:
	BY	Joshua Vasquez	3/3/2020
		SCALE: 1:1	SHEET 3 OF 14



В

Α

ITEM NO.	DESCRIPTION	QTY.
4	M3 8mm Threaded Tool Balls	3
5	M3 Flathead Screw, 6mm long	3





В

Α

Tool Ball Installation			
<u></u>	(i) BY	Created by: Joshua Vasquez	last edited: 3/3/2020
		SCALE: 1:1	SHEET 4 OF 14








Α

A

В

ITEM NO.	DESCRIPTION	QTY.
1	Compression Flexure	1
2	Right Parking Wing	1
3	Left Parking Wing	1
4	M3 Buttonhead Screw, 6mm long	2

Parking Wing Assembly			
	(i)	Created by:	last edited:
<u></u>	BY	Joshua Vasquez	3/3/2020
		SCALE: 1:1	SHEET 5 OF 14



ITEM NO.	DESCRIPTION	QTY.
1	Left Parking Wing Assembly	1
2	Right Parking Wing Assembly	1
3	Base Tool Plate Assembly	1
4	M3 Flathead Screw, 6mm len	8

Tool Plate Assembly			
(i)	Created by: Joshua Vasquez	last edited: 3/3/2020	
ву	SCALE: 1:1	SHEET 6 OF 14	

Follow the V6 or Volcano Hotend Assembly Instructions from E3D to assemble the hotend shown below.

V6 Instructions

Volcano Instructions

В

Do not clip on the hotend fan just yet.


Do not heat up the extruder to finish tightening the heat break just yet.

A

Hotend Cold Assembly			
<u></u>		Created by:	last edited:
(cc)	BY	Joshua Vasquez	3/3/2020
		SCALE: 1:1	SHEET 7 OF 14

В

•



A


ITEM NO.	DESCRIPTION	QTY.
1	Hotend Assembly with PTFE Tube	1
2	Groovemount Base with Inserts	1
3	Groovemount Clip	1
4	M3 Buttonhead Screw, 12mm long	2

Hotend Base Assembly				
		Created by:	last edited:	
<u></u>	BY	Joshua Vasquez	3/3/2020	


SCALE: 1:1


SHEET 9 OF 14


В














А

В

ITEM NO.	DESCRIPTION	QTY.
5	Fan with Shroud	1
6	M3 Buttonhead Screw, 6mm long	2

Fan Installation				
<u></u>	(i) BY	Created by: Joshua Vasquez	last edited: 3/3/2020	
		SCALE: 1:1	SHEET 14 OF 14	

В